


# Access control run by your software

## How a scan becomes an open gate



## How DeltaQuest compares

|                        | Traditional access control<br>Paxton salto GALLAGHER                         | CRM-specific access control<br>ASHBOURNE xplor resamania                     | DeltaQuest                                                                         |
|------------------------|------------------------------------------------------------------------------|------------------------------------------------------------------------------|------------------------------------------------------------------------------------|
| <b>Member data</b>     | Synced into the access system's own database, so you keep two copies in step | Held in the vendor's own membership software                                 | Stays only in your platform. No user database to push to or pull from              |
| <b>Decisions</b>       | Made by the access system from its copy of your data                         | Made by the vendor's software, for its own members only                      | Made live by your API on every scan, using your own rules                          |
| <b>Software choice</b> | Each platform builds and maintains an integration per brand                  | Tied to one vendor. Changing software usually means replacing access control | Around 30 platforms already integrated. Operators keep the hardware if they switch |
| <b>Tap events</b>      | A separate listener or event feed to build and maintain                      | Built in, but only inside the vendor's own system                            | Every tap already reaches your API, so sign-in and sign-out need nothing extra     |

**32**

access points per host connection

**30**

software platforms already integrated

**64**

characters max via RS232 or RS485

**TCP/IP**

or USB serial to the host

**1992**


designed and built in Cwmbran since

# Two ways to integrate

## ROUTE 1

### Build your own integration layer

You build the integration layer into your platform using the DeltaQuest command protocol.




|                   |                                                                              |
|-------------------|------------------------------------------------------------------------------|
| <b>Best for</b>   | Teams that want to own the access layer end to end                           |
| <b>Who builds</b> | Your team, with our protocol docs and engineering support                    |
| <b>Runs on</b>    | Your software, on a site PC or your own on-site service                      |
| <b>Cost</b>       | No integration charge. The operator buys the hardware once, with no licence. |

## ROUTE 2

### Let Nortech provide the DeltaQuest Hub

Nortech builds and supports a Hub that speaks DeltaQuest on one side and your API on the other.



|                   |                                                                                 |
|-------------------|---------------------------------------------------------------------------------|
| <b>Best for</b>   | Platforms with a membership API that would rather not write access control code |
| <b>Who builds</b> | Nortech, against your API and sandbox. We write, test and support it.           |
| <b>Runs on</b>    | Windows, Linux, an embedded PC or a Raspberry Pi, supplied pre-configured       |
| <b>Cost</b>       | Annual licence per controller, paid by the operator. No charge to you.          |



#### Switch routes later

Same controllers and readers on both. An operator can start on the Hub and move to a direct build without touching site hardware.



#### Sell it under your own brand (OEM)

We make it and you sell it as yours, with your brand on the box, as part of a complete package. Ask us about OEM supply.

## HUB ROUTE

### Getting your first site live

1

#### Agree the API

One technical call. You share your endpoint and sandbox details, and we confirm the request and response shape.

2

#### Build and test

Nortech builds the Hub against your sandbox and tests it with your team. Around a week of development once scheduled.

3

#### Go live and roll out

The first site is set up remotely with the operator. Later sites follow the same process.

## EXISTING SITES

### Sites already running CRC400s

#### No new controllers

CRC400 uses the same host protocol as DeltaQuest, so the Hub connects to what is already installed.

#### No engineer visit

We configure the Hub over a remote session and test it with the operator, unless something physical needs changing.

#### Any site layout

One Hub runs several controllers over TCP/IP or USB serial. Separate buildings can run their own Hub into the same endpoint.




#### Off the reception PC

Runs on Windows, Linux, an embedded PC or a Raspberry Pi, so reboots and COM-port clashes stop breaking access.

# How the integration works

Deltaquest Integration Guide  
 For Software Partners  
 REF NTC-DQ-INT-2026

## What gets sent



### Request to your endpoint

|            |          |                             |
|------------|----------|-----------------------------|
| reader     | R1       | which reader was scanned    |
| credential | 7F3A...  | string read from the reader |
| site       | LOC-0042 | your ID for the venue       |
| timestamp  |          | when the scan happened      |

### Response from your endpoint

|        |               |
|--------|---------------|
| result | allow or deny |
|--------|---------------|

Optional extras can be agreed, such as a reason code. Nothing else opens the gate.

## Credential rules

# 64

### Up to 64 characters

For readers connected via RS232 or RS485. In most integrations, credentials are 32 characters or fewer.

# CRM

### Your platform sets QR expiry

Your CRM or app generates dynamic QR codes and sets their expiry, such as 10, 30 or 60 seconds. DeltaQuest just reads the code and passes it on like any other credential.

# QR+

### QR prefix

Let your platform identify QR credentials by generating codes as QR followed by the credential.

## What we need to build your Hub

- ✓ **Base URL**  
Of your access endpoint, per site or per customer instance
- ✓ **Location or site ID**  
The one your platform uses, so each scan arrives tagged with the right venue
- ✓ **Client ID and secret**  
Or your preferred auth, issued at venue level
- ✓ **Request and response format**  
Usually a thin wrapper around your existing access logic. We review it together first.
- ✓ **A sandbox**  
With test members, so every path is checked before the first site
- ✓ **Reader-to-door map**  
For each site, which readers open which gate and whether each is entry or exit

## Questions software teams ask

### Do we host anything for Nortech?

No. Nortech runs no cloud. The Hub sits at the venue and calls your API, so your platform stays the system of record.

### Where does the reader-to-gate mapping live?

In the Hub config for each site. Your platform answers allow or deny and the Hub fires the right relay. It can send you the map whenever it changes, so both systems stay in step.

### Our platform has no entry or exit concept. Is that a problem?

No. The Hub can hold which readers are entry and which are exit for each site, so you don't need to add it first.

### What happens if the connection drops?

DeltaQuest has an offline mode. By default members are let through while the link is down, and this is agreed per site at setup.

### Which readers and turnstiles can we use?

Any reader with a Wiegand, Clock & Data, RS232 or RS485 output, including QR, face and ANPR readers and ones you make yourself. Any relay-driven door, turnstile or barrier works too.

### Is this only for gyms and leisure?

No. The same setup runs behind sports club, spa, hotel and holiday-park platforms, and staff and visitor doors work the same way as gates.

## TERMS WE USE

### Reader (R1)

The scanner a member used, sent as R1, R2 and so on

### Relay

The output DeltaQuest switches to open a door, gate or barrier

### Integration layer

The software between DeltaQuest and your API

### DeltaQuest Hub

Nortech's version of that layer, built for your API

### OEM

We make the controller and you sell it under your brand

## Talk to an Engineer

## Amer Hafiz, Technical Director

Sign our NDA and we'll send the protocol pack and a test controller, or scope a Hub against your API docs. We can also help line up pilot sites for your beta.

+44 (0) 1633 485533,


[info@nortechcontrol.com](mailto:info@nortechcontrol.com),

[nortechcontrol.com](http://nortechcontrol.com)

# What connects to DeltaQuest

If a reader outputs Wiegand, Clock & Data, RS232 or RS485, it connects. Each output is a relay your software fires, so the same API call can open a turnstile on one site and a car park barrier on the next.


## READERS AND INPUTS



## CONTROLLER



## OUTPUTS



**USB or TCP/IP**  
Up to 32 access points per link



## One site, mixed hardware

An example leisure site on a single controller network

